

LiftMaster®


REMOTE LIGHT CONTROL MODEL 825LM

OVERVIEW

The Remote Light Control module offers a quick and convenient way to control the lights in your home. The module can be programmed to a remote control, a garage door opener, or a MyQ™ Internet Gateway Accessory. The module is compatible with up to 8 Security+ 2.0™ remote controls **OR** a combination of up to 8 MyQ™ enabled garage door openers or MyQ™ Internet Gateway Accessories. This product is NOT to be used for appliances.

SPECIFICATIONS

Fluorescent600W / 5A
Tungsten.....600W / 5A
LED600W / 5A
Electronic Ballast (Fluorescent) 599W / 4.99A
Re-lamp with listed SBCFL only, 599W total, maximum



⚠ WARNING

To prevent possible **SERIOUS INJURY** or **DEATH** from electrocution or fire, the light control is **ONLY** for indoor use.

NOTICE: To comply with FCC and/or Industry Canada (IC) rules, adjustment or modifications of this transceiver are prohibited. THERE ARE NO USER SERVICEABLE PARTS.

This device complies with Part 15 of the FCC rules and IC RSS-210. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MODES OF OPERATION

The module can be programmed to a Security+ 2.0™ remote control, a MyQ™ enabled garage door opener, or a MyQ™ Internet Gateway Accessory.

REMOTE CONTROL OPERATION:


Allows you to activate the module from a remote control.



GARAGE DOOR OPENER OPERATION:

Allows you to synchronize the module with your garage door opener light bulbs.

Example: The garage door opener light bulbs are set to automatically turn off after 4 ½ minutes, the module will also turn off after 4 ½ minutes.




MyQ™ GATEWAY OPERATION:

Allows you to activate the module from a web browser or smart phone (requires the MyQ™ Internet Gateway Accessory, Model 828LM).




INSTALLATION & PROGRAMMING


- 1** Plug the lamp into the module and plug the module into an electrical outlet (the LED on the module will flash). **NOTE:** Make sure the lamp is switched ON.




- 2** If the lamp is not ON, press and release the Power button on the module to turn the lamp ON.




- 3** Press and release the Learn button on the module (the LED on the module will light).



- 4** Press the button on the remote control. **OR** Press the Learn button on the garage door opener. **OR** Visit www.myliftmaster.com. Go to "Manage Devices", then "Learn Device" to program the MyQ™ Internet Gateway Accessory.



The lamp's light bulb will blink and the LED on the module will turn OFF when the device has been programmed.



TO ERASE ALL PROGRAMMING

Press and hold the Learn button on the module for 6 seconds. All programming is now erased.

ONE YEAR LIMITED WARRANTY

The Chamberlain Group, Inc. warrants to the first retail purchaser of this product that is free from defect in materials and/or workmanship for a period of 1 year from the date of purchase.

LiftMaster®

APERÇU

Le module de télécommande offre un moyen rapide et pratique de commander l'éclairage à la maison. On peut le programmer pour une télécommande, un ouvre-porte de garage, ou un accessoire MyQ™ Internet Gateway. Il est compatible avec 8 Security+ 2.0™ télécommandes **OU** ouvre-portes de garage MyQ™ ou accessoire MYQ™ Internet Gateway, au maximum 8. Cet appareil ne doit PAS être utilisé pour les appareils ménagers.

CARACTÉRISTIQUES

Fluorescent 600W / 5A
Tungstène 600W / 5A
DEL 600W / 5A
Ballast électronique (fluorescent) 599W / 4,99A
Remplacement par une lampe de type SBCFL uniquement, 599W au total, au maximum

MODES DE FONCTIONNEMENT

Le module peut être programmé pour une Security+ 2.0™ télécommande, ou un ouvre-porte de garage MyQ™, ou un accessoire MYQ™ Internet Gateway.

FONCTIONNEMENT DE LA TÉLÉCOMMANDE :


Permet d'activer le module à partir d'une télécommande.



FONCTIONNEMENT DE L'OUVRE-PORTE DE GARAGE :


Permet de synchroniser le module avec les ampoules d'ouvre-porte de garage.

Exemple : Les ampoules de l'ouvre-porte de garage sont programmées de façon à s'éteindre automatiquement après 4 minutes et demie, le module se désactivera également après 4 minutes et demie.




FONCTIONNEMENT BARRIÈRE MyQ™ :

Permet de faire fonctionner le module à partir d'un navigateur Web ou d'un téléphone intelligent (nécessite l'accessoire MYQ™ Internet Gateway, Modèle 828LM).




INSTALLATION ET PROGRAMMATION


1 Brancher la lampe au module, puis brancher ce dernier à une prise électrique (le témoin DEL du module va clignoter). **REMARQUE :** Assurez-vous que la lampe est allumée.



2 Si la lampe n'est pas allumée, appuyer brièvement sur le bouton d'alimentation du module pour l'allumer.



3 Appuyer brièvement sur le bouton de programmation du module (le témoin DEL du module va s'allumer).



4 Appuyer sur le bouton de la télécommande.





OU

Appuyer sur le bouton de la télécommande.

OU

Visitez www.myliftmaster.com. Cliquez sur "Manage Devices" (gestion dispositifs), puis sur "Learn Device" (dispositif "Learn") pour programmer l'accessoire MyQ™ Internet Gateway.

Une fois que le dispositif est programmé, l'ampoule de la lampe va clignoter et le témoin DEL du module va s'éteindre.



POUR SUPPRIMER TOUTE LA PROGRAMMATION

Appuyer sur le bouton de programmation du module et le maintenir enfoncé pendant 6 secondes. Toute la programmation sera alors supprimée.

GARANTIE LIMITÉE DE UN AN

The Chamberlain Group, Inc. garantit ce produit au premier acheteur au détail contre tout défaut de matériel ou de fabrication pendant une période d'un an à compter de la date d'achat.

TÉLÉCOMMANDE D'ÉCLAIRAGE MODÈLE 825LM

⚠ AVERTISSEMENT

Pour éviter d'éventuelles BLESSURES GRAVES ou LA MORT par électrocution ou incendie, la commande d'éclairage n'est réservée qu'à un usage intérieur.

REMARQUE : Pour être conforme aux normes de la FCC et d'Industrie Canada (IC), il est interdit d'ajuster ou de modifier ce récepteur. IL N'Y A AUCUNE PIÈCE QUE L'UTILISATEUR PEUT RÉPARER.

Cet appareil est conforme à la Partie 15 du Règlement de la FCC et à la norme CNR-210 d'IC. Son fonctionnement est soumis aux deux conditions suivantes : 1) cet appareil ne doit pas causer d'interférences nuisibles et 2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent perturber le fonctionnement.