



Miller Edge Transmitter Installation Instructions

(Models MWT02 and MWTA02)

2 Wire Edge Only

Read the following instructions thoroughly before using the transmitter.

This transmitter must be adjusted so that the coding switches match the coding switches on your existing Miller Edge operating transmitters or receivers.

NOTE: Miller Edge wireless devices are not compatible with other manufacturer's wireless devices.

FCC Regulation:

This device complies with the FCC Rules Part 15

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
 - 2) This device must accept an interference that may cause an undesired operation.
- * Transmitter distance may vary due to circumstances beyond our control.

Setting the Code for the Single Entry Transmitter (Models MWT02 and MWTA02)

You may set your transmitter to any code you desire, but be sure the code you set matches on both your transmitter and receiver. There are nine (9) coding switches, each of which can be placed in three different positions (+, 0, -). **DO NOT** set all switches in the same position, such as all +, all -, or all zero (Figure A).

WARNING: No other adjustments should be made inside the transmitter. Now that you have selected your personal code, replace the transmitter cover.



Figure A

* Mount transmitter box directly to gate post or door. **NOTE: DO NOT** drill any holes in the transmitter box. Use only mounting holes provided, any additional holes in transmitter box will cause water to enter and a loss of warranty.

BATTERY INSTALLATION

